

Safety Alert



Stockholm Arlanda Airport 2026-01-19
Safety Alert 69

Important - before activating the Docking Guidance System!

To ensure a safe and correct aircraft arrival, the docking guidance system must **only** be activated once the stand has been verified as ready. Before activation, confirm the following conditions within the

Equipment Restraint Area (ERA):

✓ FOD Check

The area must be **free of Foreign Object Debris (FOD)** in accordance with the aerodrome's FOD management program.

⊘ GSE and Vehicles

The ERA must be **clear of Ground Support Equipment and vehicles**, as required under apron management and stand safety procedures.

🚫 Unauthorized Personnel

No unauthorized personnel may be present inside the ERA, in line with apron access control and safe working area rules.

❄️ Surface Condition

The stand surface must be checked and, if required, treated to ensure it is **free from glycol contamination**, according to the aerodrome's de-/anti-icing fluid management and environmental procedures.

⚠️ Other Hazards

Any additional hazards or abnormal conditions that could affect safety or operational integrity must be identified and mitigated before activation, in accordance with the aerodrome's Safety Management System (SMS).

Please note! If **any** of the conditions above are **not fulfilled**, the docking guidance system **must not** be activated.